

RAF Super Taskmaster tractor

Assembly diagram & notes

For 1:72 & 1:48 versions

Remove all flash,
mould lines or
feed stubs from all parts.
Assemble parts with
cyanoacrylate
adhesive (super glue)
or epoxy cement.
Drill holes as necessary
for locating pins of parts.
Etched brass parts have
identifying numbers on fret.

