



# TRANSPORT WINGS

1:72 multi-media conversion pack

## TWC72016

# XCG-17 Dakota Glider

For use with the Airfix Dakota kit (2015 release)

## Instructions

- 1 Assemble the kit in accordance with the instructions. but do not attach any nacelle, engine or exhaust parts.
- 2 Remove all flash or mould lines from the nacelle fairings and the tow fitting.
- 3 Attach the conversion parts with epoxy cement or cyanoacrylate (superglue).
- 4 Attach a nacelle fairing to the front of each nacelle and hold them in position until the glue has set.
- 5 Attach the towing fitting between the stress angles on the underside of the centre section. The front of the towing fitting is level with the front of the stress angles.

